

# Default Radio Setting

**Squelch Switch rotate counter clockwise all the way.**

*This controls how loud you must speak before you are able to hear yourself in your headset. When you are flying, you may want to turn to 9 o'clock position to get rid of static noise.*

**Intercom Volume Switch to 9 o'clock position.**

*This controls the volume of the voices within the aircraft. If your passengers can't hear you speak, it is possible that this is too low. This knob has no effect on the volume level of any radio calls.*

**XMT (Transmit) Green Light on COM2**

*In this picture, Com1 radio is OFF and Com2 radio is turned ON, therefore Com2 XMT Button light should be on as shown. If Com1 light is on, but Com2 radio is on, you will not be transmitting anything. Ensure the same light is on, as the radio you have turned on.*

**Intercom System (ICS) Green Light on "All"**

*This button allows you to isolate only your headset (ISO), isolate the front seats (CRW) or to be able to hear everyone (ALL)*

**RCV (Receive) Green Light On Com2**

*The same light that is on for transmit (XMT) needs to be on for receive (RCV) or you will not be able to hear radio calls made on the frequency.*

**Tuning Knob**

**Flip Flop Button**

**Com 1**

**Com 2**

**Volume Knob to 2 O'clock Position**

*This knob controls the volume that you hear all radio calls. The 2 o'clock position corresponds to about 50% volume.*

**Frequency Set Correctly for Airport**

*Set freq with Tuning Knob. Push Flip/Flop button to move freq to left side. Ensure freq set.*

